

INSTRUCTION MANUAL FOR *W-PANIC*

**Wireless Emergency (Duress) Button
for use with PIMA W-Receiver.**



40 Prof. Shor St. Holon 58816, Israel
Tel: 972+3+5569313
Fax: 972+3+5500442
E-mail: sales@pima-alarms.com
Web: www.pima-alarms.com


Introduction

The Pima *W-PANIC* is a simple to use emergency button, which is battery operated and communicates with your Pima *W-Receiver* via a fixed code radio transmission (RF). Pressing the button firmly causes the LED light to come on & the button to transmit to your receiver.



Setup

1. Remove the rear cover by removing the three case screws.
2. Select a transmission code for your emergency button by moving any of the dipswitches numbered 2 - 8 into a random combination of up, down or middle for each switch.
Note: Do not move dipswitch Number 1 from the default position (middle).
3. If you are utilising more than one emergency button with your PIMA *W-Receiver*, you can either code your emergency buttons the same so that they activate the same channel on your receiver, or you can code them differently to activate different channels.
4. Refer to your PIMA *W-Receiver* Manual for learning procedure [same as Wireless PIR Detector].



Specifications:

Power Supply: 12VDC Alkaline Battery Type 23A
Standby Current: 10 μ A

Operation Current: 5mA
Warranty: 12 Months